

# **USER MANUAL**

## **POCKET BIKE PB-G02**



# MINIBIKE-PMI

SERVICE MANUAL FOR USE AND MAINTENANCE AND SPARE PARTS LIST For your own safety and the safety of others Follow these recommendations in order to use your MINIBIKE safely and correctly. Read the instructions CAREFULLY, failure to do so may place yourself and others in extreme and or ultimate DANGER. If you do not understand the instructions and Data then, you are not to attempt to operate this Minibike under any circumstances. It may be used for show purposes only!

## CONTENTS

	<b>PAGE</b>
INTRODUCTION.....	2
TECHNICAL DATA.....	2
UNPACKING AND SETTING UP BEFORE RIDING.....	3
SAFETY.....	3
BEFORE STARTING.....	3
STARTING THE ENGINE .FIG. 2.....	4
CARBURETOR.FIG. 3.....	4
RIDING.....	4
PERIODIC MAINTENANCE.....	5
CHAIN SETTING AND MAINTENANCE.....	5
CENTRIFUGAL CLUTCH REPAIR OR REPLACEMENT.....	5
BRAKES ADJUSTING .FIG. 4.....	6
FRONT BRAKES PADS REPLACEMENT .FIG. 7.....	6
REAR BRAKES PADS REPLACEMENT.FIG. 7.....	6
REMOVE AND REFIT THE FRONT WHEEL.FIG. 5.....	7
REMOVE AND REFIT THE REAR WHEEL . FIG. 5.....	7
REPLACEMENT OF SPROCKET -FK3.9.....	7
ENGINE.....	8
POCKET BIKE PB-G02 .FIG. 5.....	9, 10
PARTS LIST.....	11 12
FRONT AND REAR BRAKES .FIG. 7.....	13
REPLACEMENT OF TIRE .FIG. 5.....	14
DISMANTCING AND ASSEMBLY OF AIR FFLTER-FIG.3.....	14
WHAT TO DO BEFORE A PERIOD OF IDLENESS.....	14

## INTRODUCTION

The Minibike -PB-G02 is designed and built for use on a paved closed circuit track. The track should be clean and without obstacles of any kind. Qualified adults and younger persons can drive the minibike. Children can drive the minibike only under the supervision of a responsible adult person. The minibike is constructed especially for racing competitions on special racing tracks. The minibike uses a single-cylinder two-stroke, Gasoline combustion engine, and has an air filter and exhaust silencer. Transfer of power to the rear wheel is through a drive chain. The overall drive ratio to the rear wheel can be changed by the replacement of chain sprockets. The front and rear wheel is equipped with disk brakes. The rear brake is controlled with the left fever and the front brake is controlled with the right lever on the handlebars.


### BASIC TECHNICAL DATA

<u>ENGINE:</u>	MT-A1.....	TWO-STROKE
	NUMBER OF CYLINDERS.....	1
	SIZE, CAPACITY.....	47 cc
	ENGINE COOLING SYSTEM.....	AIR COOLED
	POWER OUTPUT.....	2.5kW at 8700rpm
	CARBURETOR.....	DELL'ORTO
	FUEL ADMISION.....	REED VALVE DIRECT TO CRANKCASE
	IGNITION.....	ELECTRONIC
	SPARK PLUG.....	NGK B9 ES
	STARTING.....	HAND PULL TYPE, MANUAL
	CLUTCH.....	CENTRIFUGAL, FRICTION
<u>FRAME:</u>	WELDED.....	HIGH STRESS STEEL TUBES
<u>BRAKES:</u>	FRONT WHEEL.....	DISC BRAKES
	REAR WHEEL.....	MECHANICAL BRAKES
<u>WHEELS:</u>	FRONT.....	OF LIGHT ALLOY 6, 5" - 63
	REAR.....	OF LIGHT ALLOY 6, 5" - 63
<u>TIRE:</u>	FRONT.....	SIZE 90/65 - 6, 5"
	REAR.....	110/50 - 6,5", 90/65 - 6,5"
<u>FUEL:</u>	PETROL (GASOLINE).....	OCTANE 92 +SYNTHETIC OIL
	MIXING RATIO (after break in period).....	50:1
	TANK CAPACITY.....	1 Litre
<u>SPEED:</u>	WITH THE INSTALLED RATIO:.....	up to28mph(45km/h)
<u>UNLOADED WEIGHT:</u> .....		(41.5lbs.) 19 kg
<u>CARRYING CAPACITY:</u> .....		(240lbs) 110 kg
<u>BASIC DIMENSIONS:</u>		
	LENGTH.....	950 mm
	WIDTH.....	500mm
	HEIGHT.....	565 mm

## UNPACKING AND SETTING UP BEFORE RIDING

The minibike is delivered in a cardboard carton and packed with folded handlebars and brake levers. After unpacking, set up the handlebars into the position, that suits the best for driving. The maximum pulled brake lever position should not touch on the handlebar grip. After setting up, tighten the handlebar nuts 1, brake lever bolts 2, and the throttle assy. Bolts. See, Fig. 1. The level of foot rest's can be regulated by loosening the bolt M5 (914.003.01) on the handle of the foot rest (139.001.01). The foot rest can be moved to the front or back position. It is recommended to try and check the position of handlebars and foot rest's individually. While tightening the bolts and nuts, do not use an excessive force as to not damage the threads, or distort the tubes and other parts. Verify the smooth and perfect function of the Bowden cables to throttle and both brakes. Fill the fuel tank with fuel. (Gas-oil mix) Failure to use the proper oil mix ratio will result in Engine damage for which you will be responsible.

Fig. 1



### Operating controls:

1. Handlebar nut
2. Brake lever bolts
3. Throttle Assy. bolts
4. Stop switch
5. Front brake lever
6. Rear brake lever

### Range of adjusting handlebars

function position

### SAFETY

The minibike is unsuitable for public road use. It does not comply with valid Safety Standards. Unsafe and careless use of a minibike can result in serious injuries. The driver can minimize the potential risks by wearing the Safety Equipment The driver must wear safety helmet, goggles, gloves, elbow pads, kneepads, and firm footwear. The minibike cannot be *used* on wet, icy or oily surfaces. Avoid uneven surfaces and obstacles. Drive with two hands on the handlebars.

### BEFORE STARTING

It is strongly recommended to follow all the instructions about the break-in period to promote engine reliability and long life. Break-in period of the minibike is complete after the consumption of five full fuel tanks. It is important to use petrol 91 or 92 Octane fuel with synthetic oil in the ratio 25:1 and after break-in period a ratio of 50:1. Mix the gas and oil completely before putting it into the fuel tank. During the break-in period do not run the engine at maximum RPM and do not allow the engine to overheat. Check the tire inflation - 200 kPa (2 bars) or (28 to 30psi) to be commensurate with the driver's weight. The Tyre pressure should never exceed 2,5 bars, (38psi) in either the front or rear wheel.

## STARTING THE ENGINE

To be done only on the starting stand - Fig. 2. After opening the tank filling hole, fill the tank with fuel and close it by screwing-in cap. Open the petrol supply cock by turning the small lever into position "ON", Fig. 3. Set the choke lever into position "C", Fig. 3. Without turning the accelerating handle, pull gently twice the starting wire and by next quick pull start the engine. It is not allowed to pull the starting wire up to full winding off. After a short engine run, put the choke lever back to position "A" and let the engine run about 1 min. Let the Minibike on the starting stand and, if need be, adjust the no-load speed to such a rate lest coupling should take along the rear wheel. For adjustment use the adjustment screw N° 4 on the carburetor, Fig. 3.

Fig. 2





Fig. 3



1. Suction chamber
2. Sleeve screw
3. Carburetor body
4. Adjusting screw of no-load run
5. Float chamber
6. Fuel cock

## **RIDE**

After mounting the Minibike and slow turning the acceleration handle, you are starting your ride. Before braking, turn back the acceleration handle and depress slightly the front brake lever and then the rear brake lever. Beware of the wheels not to get them in skid.

The Minibike engine will be switched off by pushing the red push-button of the stop switch on handlebars. After the first half-hour ride it is necessary to check the tightening of screws and nuts, especially of the engine. Check also the brake setting.

## PERIODIC MAINTENANCE

Periodic maintenance is the best way to help the machine perform well, give longevity and provide safety and low cost operation. In addition, you will be spared from many-worries from self caused problems, resulting from poor maintenance or no maintenance. A - Before every ride:

1. Check the Cables and efficiency of brakes.
2. Check the lubrication and chain tension settings. The chain free play should be (5 mm) (.200in) After every ride clean the minibike carefully and keep it clean. Do not use aggressive cleaning detergents.
3. After 1-hour of use, wash the air filter In air drying spirits and lubricate it with special oil for air filters.
4. After 1- hour of use, check the state of the clutch pads. Review the clutch adjustment.

B. After every 5 hours of riding:

5. Check the tightness of all bolts and nuts. Tighten carefully to prevent damage to other parts.
6. Wash the air filter in gas and lubricate it with special oil for an air filters to better catch the dust.
7. Clean carefully the carburetor float chamber.
8. Check the brake pads, the thickness of brake lining cannot be less than 1 mm (.039 in). Review the basic brake adjustment
9. Check the state of the clutch pads. - the thickness cannot be less than 1 mm (.039in). Review the clutch adjustment.

C. Every time after 10 hours of riding:

10. Check the state of the clutch pads - the thickness cannot be less than 1 mm (.039in).

## CHAIN SETTING AND MAINTENANCE


To set the chain tension, loosen the Nut (920.011.01) of the axel thru the rear wheel and the nut (914.021.01) of the rear Caliper anchor plate. The required chain tension (chain free play ) is (5 mm) (.200in) and is performed by equal movement of the Axle adjustor plate (920.009.01) on the both sides of the rear wheel. When the adjustment is correct, tighten the Axle nuts and the Caliper holding nut Tighten the adjustor plate nuts both sides an extra nip, just to set them firmly. It is important to lubricate the chain regularly, to avoid excess wear and prolong effective lifetime. The lubrication is important after every ride on a wet surface. It is recommended to lubricate the minibike with special chain spray. If chain replacement is necessary, check both chain Sprockets and if there is a need to change them do it together with the chain.

## CENTRIFUGAL CLUTCH PARTS REPLACEMENT

Remove the chain guard by loosening two bolts M6 (916.020.01), Fig. 5. Loosen the chain and remove it from the sprocket. Next, loosen three bolts holding the aluminum clutch housing. Remove it together with steel clutch basket, and dismantle it Loosen the bolt from the carrier and remove the clutch from the engine. Loosen and remove the adjustable bolts and springs. Then dismantle the safety rings from pins. When all this is done, replace with new clutch slipper shoes and springs (if required) at this time. During the reassembly process follow these steps: 1. put the plate with the springs on the slipper shoes. 2. Put the plate against the carrier and mount it on the fixed pins. Fit it with the safety rings and install the adjustable bolts.

## **ADJUSTING THE BRAKES**

Fig. 4



**Fine brake adjusting:** Fine brake adjustment can be carried out on both ends of brake bowden wire by means of the screw 1 and nut 2.

**Basic brake adjusting:** It is carried out in such a way, at first, the nut 2 will be loosened and the screw 1 of fine tuning screwed-in. Loosen the locking nut 3 and tighten the adjusting screw 4 so that the wheel can be free turned. Tighten the locking nut 3.

*Don't release the wire catcher 5!*

### **FRONT BRAKE PADS REPLACEMENT: FIG.7**

At first, loosen the nut 920.006.01 of fine front brake adjustment. Screw-in fully the screw. Unscrew maximum the adjusting screw and lock it by fine tightening the nut 920.001.01. Dismantle the front wheel. Unscrew the nuts 920.008.01 on the front brake and remove the screws 911.001.01. Unscrew two screws 914.009.01 from the side of control lever on brake body and separate both bodies 512.011.00 each other. Remove the old brake pads from both parts. Slide the brake plate, fitted with pin, into the part with operating mechanism. Force on carefully the brake plate into the opposite piece. Before reassembly clean the whole brake. Assembly follows in reverse sequence.

### **REAR BRAKE PADS REPLACEMENT: FIG.7**

Before replacing the rear brake lining it is necessary to loosen the nut 920.006.01 of fine adjustment of rear brake. Screw-in fully the screw of fine adjustment. Loosen the nut 920.001.01 of basic adjustment. Unscrew maximum the adjustment screw 112.030.00 and lock it by fine tightening the nut 920.001.01. Don't release the wire catcher 512.016.00 and dismantle the rear wheel. Shift the whole brake out of the guide pins. Unscrew both screws 912.003.01 from the control lever side. Separate both bodies 112.003.00 each other and shift the worn-out brake plates out of guide pins clean carefully the brake and put the new brake plates on the guide pins so that they face by lining towards themselves. The assembly follows in a reverse way. After mounting the rear wheel carry out the chain adjustment and basic brake adjustment.

### **REMOVE AND REPLACE THE FRONT WHEEL - FIG. 5**

Before dismantling the front wheel it is necessary to remove the front brake pads from the front brake, so it is possible to move the brake caliper from the wheel and be able to draw out the wheel and tire. Remove the front axel nut. M10 (920.011.01) . Draw out the axel from the fork and wheel. Remove the wheel by an easy pull downwards from the forks. Caution, while removing the wheel the left side spacer washer will fall out! During the assembly process put the spacer washer between the brake rotor and brake caliper mount plate and the right side distance spacer between the wheel and right fork (315.011.00). Return the brake pads with the spring and tighten up the axel nut Perform the basic brake adjusting. Double check your work. This is important!

### **REMOVE AND REPLACE THE REAR WHEEL - FIG. 5**

Remove the rear wheel axel nut. Loosen the nut on the rear caliper anchor plate. Remove the two wheel adjustor plate nuts. (M6) Move the wheel forward *and* remove the chain. Safely (hold) keep the rear wheel front .ailing out while pulling out the axel. Caution, note the location of both spacer tubes and one spacer washer (between caliper mount plate and rotor) while removing wheel. When refitting *the* wheel, make sure to slide the brake rotor into the caliper between the pads. Hold the wheel in place and fit the wheel spacers in proper order, Insert the spacer washer between the caliper plate and the brake rotor *and on* the both sides place the axel spacers at the appropriate time during assembly. Adjust chain tension and tighten axel nut Tighten the caliper holder plate nut and set and tighten both chain adjustor plate M6 nuts. At this time check the brake operation. Recheck all your work. This is important!

### **PINION EXCHANGE: FIG.6**




Fig. 6


First dismantle the front lining and chain guard. Loosen the nut of rear wheel axle and the nut of chain tightener, remove chain, insert carefully a larger screwdriver or steel rod into the hole of clutch drum, Fig. 6, to avoid a turning over the clutch drum releasing the pinion. Using the socket wrench size 14 mm, release the new pinion to carried out by reverse way.





C40.00.000	MINIBIKE	E40.008.00	STARTER SPRING		<u>STEERING</u>		
E40.00.000	ENGINE	E40.009.00	RATCHET WHEEL	C40.01.004	BOWDEN OUST GUARD	C40.10.002	SCREW M5×16
E40.001.01	ENGINE COMPLETE	E40.011.00	WASHER 4.5×16×1.5	C40.02.003	CAP	C40.00.015	SCREW M 5 × 20
E40.002.00	ENGINE PROPER	E40.015.00	WASHER 8.1×16×1	C40.02.001	NUT	E40.005.01	SCREW M 5x 30
E40.004.00	CARBURETOR SHA 1412L	E40.017.00	WASHER 6.1×16 × 1.5	C40.01.901	HANO-GRIPS (PAIR)	C40.00.611	SCREW M 6 × 16
E40.004.01	PISTON COMPLETE • A	E40.020.00	PINION	C40.01.906	CAS CABLE SLEEVE ASSY	C40.13.603	SCREW M 5 × 20
E40.004.02	PISTON COMPLETE • B	E40.108.00	CONNECTING ROD BEARING	C40.01.903	THROTTLE TWIST GRIP	E40.009.01	SCREW M 6 × 22
E40.004.03	PISTON COMPLETE • C			C40.01.907	HANDLEBAR COMPLETE	E40.010.01	SCREW M 6 × 25
E40.005.00	PISTON COMPLETE • D	C40.00.000	<u>FRAME</u>	C40.02.802	FORK WITH DRAKE HOLDER	E40.010.101	SCREW M 6 × 30
E40.005.00	PISTON RING		FRAME VARNISHED	C40.02.801	RIGHT FORK	E40.001.01	SCREW M4 × 8
E40.006.00	PISTON • A	C40.10.907	<u>BRAKES</u>	C40.02.001	FORKS HOLDER ABOVE- COMPLETE (w 130)	E40.004.01	SCREW M4 × 10
E40.006.01	PISTON • B		BRAKE COMPLETE	C40.02.002	FORKS HOLDER BELOW-COMPLETE (w 130)	E40.005.01	SCREW M 6 × 16
E40.006.02	PISTON • C	107.003.00	BRAKE CASE - 1 PAIR		<u>TRANSMISSION</u>	C40.00.604	SCREW M 6 × 40
E40.006.03	PISTON • D	107.004.00	LIFTER, RIGHT	C40.10.003	SPROCKET 68TEETH	E4091606502	SCREW M 5 × 25
E40.008.00	WRIST • PIN	107.005.00	REAR PAD-2 PCS	C40.00.806	CHAJM140 LINKS		
E40.011.00	CRANK BALANCED	C40.10.004	BRAKE REACTION LIFTER		<u>ELECTRIC COMPONENTS</u>	107.001.01	NUT M5
E40.015.00	CLUTCH DISC	107.009.00	SPRING, LEFT	E40.003.00	SPARKPLUG	C40.13.601	NUT M 6
E40.017.00	CLUTCH LEVER - 2 PCS	107.015.00	BRAKE HOLDER COMPLETE	E40.002.00	ROTOR COMPLETE	107.008.01	NUT M 5 SELF-LOCKING
E40.019.00	CLUTCH SCREW COMPLETE	C40.10.016	BRAKE HOLDER	E40.001.00	IGNITION COMPLETE	C40.10.001	NUT M 6 SELF-LOCKING
E40.020.00	CLUTCH SPRING • SERIE 1.25 - 2 PCS	107.017.00	LEADING PINS	E40.005.00	SPARK PLUG CAP	C40.01.601	NUT M 8 SELF-LOCKING
E40.021.00	CLUTCH SPRING • SERIE 1.25 - 2 PCS	107.018.00	LEADING PINS	C40.01.905	KILL SWITCH	C40.03.105	NUT M 10 SELF-LOCKING
E40.022.00	CLUTCH SPRING • RACING 1.4-2 PCS	107.018.00	BOWDEN CABLE • REAR BRAKE			E40.012.01	NUT M 8 LEFT
E40.024.00	CLUTCH DRUM	107.022.00	BOWDEN CABLE • FRONT BRAKE		<u>OTHER PARTS</u>	40.003.01	WASHER 10.5
E40.023.00	CLUTCH CASE	C40.03.003	FRONT BRAKE DISC 3.0 × 119		SPACER L=258	40.010.00	WASHER 8.4
E40.031.00	CLUTCH CASE COMPLETE	C40.10.002	REAR BRAKE DISC 3.0 × 119	C40.00.608	ADJUSTING SCREW	40.011.00	WASHER 8.1
E40.032.00	CLUTCH COMPLETE	107.112.030.00	ADJUSTING SCREW	C40.00.007	BRAKE COMPLETE		
E40.053.00	ENGINE COVERING	C40.02.907	HANDLE BAR LEVER, RIGHT	C40.06.003	HANDLE BAR LEVER, LEFT	107.001.00	RIVET 4 × 8
E40.055.00	ENGINE SEALING SET	C40.01.910 512.004	UFTER, LEFT		GAS TANK WITH CAP	107.006.00	ROLLER 6 × 6
E40.056.00	FLANGE	C40.01.911 512.005	BRAKE CASE • 1 PAIR	C40.06.901	GAS TANK W/CAP		
E40.057.00	DIAPHRAGM SEALING - 2 PCS	027.008.00	DISC BRAKE PADS • 2 PCS	C40.00.004	RUBBER FRAME PAD	40.003.00	WOODRUFF KEY 3e7 × 3.7
E40.059.00	DIAPHRAGM		LIFTER LEVER	C40.00.804	STAND	40.005.00	WOODRUFF KEY 2e7 × 3.7
E40.060.00	DIAPHRAGM WASHER	027.011.00	SPRING RIGHT	C40.00.607	WASHER 6.4 × 18 × 1	43.007.00	LOCK 15
E40.063.00	SEALING ENGINE BLOCK	027.012.00	TERM. CLAMP BOWDEN	C40.05.001	RUBBER SEAT	40.006.00	LOCK 35
E40.065.00	ENGINE BLOCK	027.013.00	FRONT BRAKE HOLDER	C40.16.002	FUEL HOSE	40.010.00	PISTON PIN LOCK RING
E40.067.00	DIAPHRAGM COMPLETE	027.014.00	WASHER	C40.06.003	HOSE CLAMP 11/7		
E40.068.00	SEALING	027.016.50	ADJUSTING SCREW	C40.13.602	WASHER	960.003.00	BEARING 6000 2R
E40.069.00	CYLINDER • A	027.017.00	BOWDEN HOLDER	C40.00.901	ADJUSTABLE FOOT REST, RIGHT	960.004.00	BEARING 6200 2R
E40.069.01	CYLINDER • B	027.019.00	WHEELS	C40.00.902	ADJUSTABLE FOOT REST -LEFT		
E40.069.02	CYLINDER • C	027.024.00	SPACER L=14.5	C40.00.006	FOOT PEGS PLASTIC-PAIR	40.006.00	BEARING 6202 C3
E40.069.03	CYLINDER • D	027.025.00	CHAIN STRETCHER COMPLETE		<u>JOINING ELEMENTS</u>	40.007.00	BEARING 6202 2ZR
E40.070.00	CYLINDER + PISTON COMPLETE		TIRE 90/65-6.5×8- SLICK	C40.02.601	SCREW M 10 × 140	40.001.00	PACKUNG RING 12×22 × 7
E40.072.00	EXHAUST SEALING	C40.10.604	TIRE 110/50-6.5×8- SLICK	C40.107	SCREW M5×25		
E40.073.00	PLASTIC CONNECT, FUEL COCK	C40.10.906	WHEEL AXLE M10×220	C40.03.601	SCREW M 5 × 16	40.002.00	PACKUNG RING 15×26 × 7
E40.074.00	FUEL COCK	C40.03.901	VALVE 90°-TUBELESS	C40.01.606	SCREW M 8 × 35		
E40.075.00	EXHAUST COMPLETE	C40.10.901	WHEEL AXLE M10 × 165				
E40.076.00	EXHAUST SILENCER COMPLETE	C40.10.608	RIMVHUBASSY 6.5×-63 -90				
E40.077.00	SILENCER MASS	C40.10.902	RIMVHUBASSY 6.5", 63-130				
E40.078.00	RING	C40.03.604	WHEEL COMPLETE W/O TIRE 6.5" 63-90				
E40.080.52	JET 52	C40.03.001	WHEEL COMPLETE W/O TIRE 6.5" - 63 -130				
E40.097.00	FLOAT CHAMBER SEALING	C40.03.001	AXLE SPACER L=7				
E40.098.00	CARBURETOR SEALING 1	C40.10.001	AXLE SPACER L=84.5				
E40.099.00	ADJUSTING SCREW	C40.03.900	AXLE SPACER L=76.5				
E40.100.00	TROTTLE VALVE	C40.10.900	AXLE SPACER L=117.5				
E40.101.00	CARBURETOR FILTER	C40.03.603	<u>BODY</u>				
E40.102.00	NEEDLE VALVE	C40.02.602	CHAIN GUARD				
		C40.03.602	FRONT FENDER NOW VARNISHED				
		C40.10.602	FRONT FENDEA VARNISHED				
E40.103.00	FLOAT	C40.00.007	GLASS BODY WT COMPLETE NON VAANISHEO				
E40.104.00	CARBURETOR SEALING 2	C40.00.001	GLASS BOOY KIT COMPLETE VARNISHED				
E40.105.00	TROTTLE VALVE SEALING	C40.00.801	FAIRING NON VARNISHED				
E40.185.00	JET SET		SEAT-TA4 ASSEMBLY NON VARNISHED				
E40.002.00	STARTER COMPLETE		FAWING VARNISHED				
E40.003.00	STARTER ROPE	C40.00.003	SEAT-TALL ASSEMBLY VARNISHED				
E40.004.00	HOLDER	C40.00.002	WINDSHIELD -RIVETS				
E40.005.00	HOLDER	C40.00.803	RUBBER WASHER 5.5 × 23.5 × 5				
E40.006.00	GUIDE BUCH	C40.00.802					
E40.007.00	STARTER CASE	C40.00.805					
		C40.13.602					

### C40.02.907 - FRONT BRAKE COMPLETE



### C40.10.907 - REAR BRAKE COMPLETE




Fig.7

### **REPLACEMENT OF TIRE - FIG.5**

Remove the wheel from the minibike. For the front wheel unbolt the brake disk and for the rear wheel, the brake disk and sprocket. Deflate the tire by removing the valve stem. Place the wheel on a hard surface and press the tire bead from the wheel rim *in* to the middle relief at centre of rim. Tire is ready to be removed from the rim at this time and is done in the conventional manner. After fitting new Tire and Tube (*if necessary*) to the rim, you can inflate 28 to 30 psi. Take care to check that the tire bead is fully seated in the rim bead edge. You can now refit the wheel to the bike in reverse order to removing it. Use Caution and recheck your work always.

### **DISMANTLING AND MOUNTING OF AIR FILTER - FIG. 3**

Dismantling the air filter unscrew 2 and so ease the holder and put down the suction chamber 1. On this way you gain access to the filter that you can take off by means of screw driver. After cleaning and lubricating it with engine oil proceed the assembly on a reverse sequence.

#### **WHAT TO DO BEFORE A PERIOD OF IDLENESS:**

Should the minibike not be used for a more or less longer period, take care and make measure as follows:

- Remove petrol from the fuel tank
- Store the minibike on a smooth and dry place
- Protect it from dust
- Remove the spark plug, clean it, put some drops of fuel with oil into the cylinder, pull 2-3 times the starter rope to distribute oil drops and then screw-in the spark plug.

Thank you for your selection of our product. Our wish is that the Minibike may serve you a long time and trouble-free, contribute to your satisfaction and bring you a pleasure.